



Installation Instructions for the PQSBM Kit

Switch Board Mounting Kit for the PQS (300 + 400) Series

Switch Board Mounting Kit Components:

- 1 - "Z" bracket from diversified metal
- 1 - "3/4" galvanized coupler
- 1 - "3/4" conduit nipple
- 2 - "1/4" x "1 1/4" long hex bolts
- 2 - "1/4" hex nut (1/4 x 20)
- 4 - lock washers



Items Needed:

- Components Included w/ PQSBM Kit
- PQ Protection PQS Series (300 or 400 Mode)

Installation Instructions:

Step 1: Remove the existing screws on the bottom, left hand side of the SPD.



Step 2: Install the "Z" bracket to the bottom left hand side of the SPD, with the existing screws.



Step 3: Install the galvanized steel coupler to the bottom right hand side, thread, of the SPD.



Step 4: Install the SPD complete with the mounting kit to the top of the designated switchboard, using the conduit nipple and mounting bolts & washers.

